

**PRODUCT IS INTENDED FOR CHILDREN  
THAT ARE 2-5 YEARS OLD.**

2023-05-17

**IMPORTANT! READ CAREFULLY  
AND KEEP FOR FUTURE REFERENCE**

## **WARNING**

- DO NOT place this product near a window as it can be used as a step by the child and cause the child to fall out of the window.
- Be aware of the risk of open fires and other sources of strong heat in the vicinity of the product.
- DO NOT place this product near a window where cords from blinds or curtains could strangle a child.

## **User Instructions**

- Inspect that all parts are connected thoroughly. Tighten screws if necessary.
- If product is broken or damaged in a way that jeopardizes function or safety, contact Lekolar for support. See contact information below:

Customer service 0479-19900  
Switchboard 0479-19800  
Kundtjanst@lekolar.se  
Address: Hallarydsvägen 8, 283 36 Osby  
PO Box: Box 170, S-283 23 Osby

- Only use Lekolar spare parts.
- Clean product with a damp cloth.